

**HAUGER**  
TIMELESS CRAFTSMANSHIP

## **CONGRATULATIONS**

We would like to congratulate you on having chosen one of our Hauger watches.  
With passion for exquisite styles and timeless craftsmanship, our watches are built  
with exclusive components from all over the world.

**HAUGER**  
TIMELESS CRAFTSMANSHIP



**WATCH MANUAL  
INSTRUCTIONS**



**EXCELLENCE V MASTER  
AUTOMATIC 44MM**

Our movements are carefully chosen from the best suppliers in Switzerland and Japan. The metal parts are all made of the highest quality polished marine 316L stainless steel. All our watches have anti reflective and scratch resistant domed Sapphire crystal glass. The leather bracelets are made in genuine italian calf leather.

The water-resistance of all Hauger watches are 100m (10ATM)

# WATCH SPECIFICATIONS


## Technical specifications

**Material:** 316L Marine grade stainless steel or Diamond Like Carbon (DLC) coated  
**Diameter:** 44mm without crown  
**Height:** 14.5 with solid back  
**Length:** 53mm lug to lug  
**Lug Width:** 24mm  
**Finish:** Polished with brushed sides  
**Water Resistance:** 100m/330ft  
**Case Back:** Solid steel screwed  
**Crystal:** Domed, scratch-resistant sapphire crystal with anti-reflective treatment inside  
**Dial:** Applied luminous indexes  
**Bezel:** Polished  
**Hands:** Sword hands with luminous  
**Crown:** Polished  
**Bracelet:** Stainless Steel with brushed screw links (instead of pins) and two button clasp and two button slidelock extension system (no need for half links)  
**Watch Case:** Delivered with a special customized wooden watch box

## Movement

**Caliber:** Miyota 8217  
**Functions:** Hours, minutes, central seconds, date calendar, 24 hr subdial  
**Total Diameter:** 11½” 26mm  
**Height:** 5.67mm  
**Jewels:** 21 Jewels  
**Power Reserve:** 42 Hours  
**Beat Rate:** 4Hz/21'600 vibrations per hour /Novodiac Shock Absorber  
**Accuracy:** -20/+40 seconds per day

# WATCH SETTINGS



## Display and functions

1. Hour hand
2. Minute hand
3. Seconds hand
4. Date display
5. 24Hour Hand

### **6. Crown with 3 positions**

I. Winding the mainspring Automatic winding watch can also be hand wound by turning the crown in "I" position. Wind 15~20 times clockwise until second hand starts to move naturally.

II. Setting the Date. Pull the crown to "II" position. Turn the crown counter-clockwise to set the date. \*If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day. After the date has been set, push the crown back to the normal position.

III. Setting the Time. Pull the crown to "III" position. Turn the crown to set the hour and minute hands.

# WATCH SETTINGS

## Usage / Settings

### **Models with a screwed crown**

To ensure that they remain water-resistant, some models are fitted with a screwed crown. Before proceeding to setting the time or date\*, you must first unscrew the crown before pulling it out to its outer positions.

**Important: After each operation, you must always screw the crown back down to ensure that your watch remains water-resistant**

### **Setting the time**

Carefully pull the crown into position **III** (3); the watch stops at this point. Turn the crown forwards or backwards until the hands display the correct time.

### **Advice on how to synchronise your watch**

To synchronise the seconds hand (3) with an official time signal (radio/TV/Internet), pull the crown out into position **III** when the seconds hand reaches the 60 second (or 12 o'clock) position. This then stops. At the tone, press the crown back into position **I** (and tighten it down if you have a model with a screwed crown).

### **Rapid correction of the date\***

**Important: Do not set the date\* between 10pm and 2 am (the movement is in the process of changing date at these times), if your model have a screwed crown.**

Pull the crown out into position **II** and turn it backwards until the correct date (4) is displayed. During this operation, your watch will continue to function normally, so you will not need to alter the time.

**Note:** When setting the time, if the chronometer is engaged, the hand on the 12-hour counter will turn together with the hour hand of the watch.

### **Winding**

Manual winding is necessary if you have not been wearing your watch for some considerable period of time. To restart it, you only need to turn the crown a few times (clockwise), or to tilt your watch from side to side a few times. To restore the power reserve of your watch, you need to turn the crown about 30 times (clockwise).

Whenever you wear your watch, the automatic mechanism is wound every time you move your wrist.

## Care and maintenance

We would advise you to clean your watch regularly (except for the leather strap) using a soft cloth and warm soapy water. After immersion in salty water, rinse it in fresh water and leave it to dry completely.

Do not leave it anywhere where it might be subjected to major variation in temperature or humidity, in direct sunlight or near strong magnetic fields.

To benefit from the highest standards of service and to ensure your guarantee remains in force, please always contact an authorised high-end watch dealer.

The high-quality mechanism of your HAUGER watch will give you complete satisfaction for many years provided that you take proper care of it. However, we would advise you to have your watch inspected every 3 to 4 years by an authorised high-end watch dealer.